

# *THE APOLLO*

PAINT YOUR WORLD  
WITH LIGHT



# ***GREETINGS EARTHLING***



The Apollo

## -INDEX-

- WHAT'S INSIDE
- HOW TO LOCK / UNLOCK YOUR APOLLOS
- CHOOSING YOUR COLORS
- CHOOSING YOUR PATTERNS
- ADJUSTING COLOR TINT
- ESCAPE FUNCTION & FACTORY RESET

PG 2

PG 3

PG 4

PG 6

PG 7

PG 8



# ***INSIDE YOUR SPACESHIP:***



1 Pair White Gloves

10× Apollo chips




10× Stardust Cases (top)

10× Stardust Diffusers



10× Stardust Cases (bottom)



20× CR1225 batteries



# ***HOW TO LOCK / UNLOCK & BASIC FUNCTIONS***

The first time you open your Apollos, they will be in LOCK mode.



To **LOCK** – Make sure light is off. Hold button down until **ALERT RED** flashes, release button immediately. Your light will then be locked.



To **UNLOCK** - Hold button down until **ALERT RED** flashes, release button immediately. Your light will now be **on**.



To **TURN ON** light, click button while light is off.

To **TURN OFF** light, hold the button in any Colorway until the light turns off, then release immediately.



To **CYCLE** through colorway slots click button while the light is on.

# DEFAULT COLORWAYS

There are 6 Colorway Slots

To the right are the default Colorways that come installed on your Apollo lights.

You can customize each Colorway with ONE Flashing Pattern and up to SIX Colors with THREE brightness levels per color.

Colorway Slot 1		
Flashing Pattern: Full Strobe		
#	Color	Bright
1	Warm White	High
2	Red	Low
3	Purple	Medium
4	Warm White	Low
5	Red	Medium
6	Purple	Low

Colorway Slot 2		
Flashing Pattern: Dops		
#	Color	Bright
1	Blue	High
2	Silver	Low
3	Green	High
4	Blue	Low
5	Silver	High
6	Green	Low

Colorway Slot 3		
Flashing Pattern: X Flash		
#	Color	Bright
1	Lavender	High
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-

Colorway Slot 4		
Flashing Pattern: Supertight		
#	Color	Bright
1	Sky Blue	High
2	Blue	Low
3	Purple	High
4	Red	Low
5	Orange	High
6	Green	Low

Colorway Slot 5		
Flashing Pattern: Hyper Strobe		
#	Color	Bright
1	Yellow	High
2	White	Medium
3	Blue	Low
4	-	-
5	-	-
6	-	-

Colorway Slot 6		
Flashing Pattern: Bit Blink		
#	Color	Bright
1	Turquoise	High
2	For. Green	Low
3	Turquoise	Medium
4	For. Green	High
5	Turquoise	Low
6	For. Green	Medium


# COLOR SELECTION



You can customize each Colorway by choosing up to 6 of the above colors:

1. Turn the light on and cycle to the colorway you want to customize. Hold button until **ALERT ORANGE** flashes and release. Blank (**FLASHING WHITE**) will display. You are now in color selection mode.
2. Click button until you reach the color you want to select.
3. To select the color on High Brightness hold button for one second and release after one blink. For Medium Brightness, hold an additional second and release after the second blink. For Low Brightness, release after the third blink. (Blank only has one brightness option.)
4. Your color will blink once and will return back to Blank. You have now selected your first color.
5. You can repeat this process to select up to SIX colors or as few as ONE color.
6. To save changes and finish Color Selection, cycle to Blank, hold button until **ALERT RED** flashes, release to exit.
7. To quit Color Selection without saving changes, hold the button down for TWELVE seconds until the light turns off, or simply leave it inactive for THIRTY seconds.

# FLASHING PATTERN SELECTION



\*example colors based on default colorways

You can choose one of the above Flashing Patterns for each Colorway.

1. From ON mode, click button to until you reach the Colorway you want to change. Hold button until **ALERT BLUE** flashes, release. You are now in Flashing Pattern Selection mode.
2. You will see the Colorway's currently selected colors in the Full Strobe flashing pattern.
3. Click button to cycle through the 6 flashing patterns. Once on desired pattern, hold button for three seconds until light flashes **ALERT ORANGE**, and release. You will be returned to the Colorway in ON mode with your new flashing pattern.
4. Holding button past alert orange will return you back to pattern selection mode.
5. To quit Flashing Pattern Selection without saving changes, hold the button down for TWELVE seconds until the light turns off, or simply leave it inactive for more than THIRTY seconds.

# ***FACTORY RESET***

Use factory reset when you want to reset your Apollos to its original default modes.

1. When light is off, hold button for five seconds until flashing **ALERT WHITE** appears, release immediately.
2. A **PURPLE** color will flash when the reset is completed. The light will turn OFF.

***3, 2, 1, LIFTOFF...***

Enjoy your Apollos!

For any questions please message Throwlights at [customerservice@throwlights.com](mailto:customerservice@throwlights.com)

Follow us! @Throwlights

